

Info

- Device Settings Turntable -

Name: Turntable

Position unit: °

Mode: Step Continuous



Stepwidth: 1.00°

Decimal place: 2

Limits

Speed

Settings

Exit